



TIP TRIMMING SUGGESTIONS

BANZAI Hybrid Iron (.370" tip)

Head loft	15/16	18/19	22/23	26/27	30/31
Tip Trim	0"	1/2"	1"	1.5"	2.0"
Butt Trim to Length					

BANZAI Hybrid Fairway (.335" tip)

Head number	3	5	7	9	11
Tip Trim	0"	1/2"	1"	1.5"	2"
Butt Trim to Length					

Speeder 904HB

Head loft	15/16	18/19	22/123	26/27	30/31
Tip Trim	No Tip Trimming				
Butt Trim to Length					

ZCOM

Standard Blind Bore Hosel

Head number	1	3	5	7	9
Tip trim	2"	2"	2.5"	3"	3"
Butt Trim To Length					

Short Hosel Bore-thru

Head number	1	3	5	7	9
Tip trim	1"	1"	1.5"	2"	3"
Butt Trim to Length					

Extended Hosel Bore-thru

Head number	1	3	5	7	9
Tip trim	0"	0"	.5"	1"	3"
Butt Trim To Length					

Vista Pro 70 Irons

Head number	2	3	4	5	6
Tip trim	.5"	1"	1.5"	2"	2.5"
Butt Trim To Length					

Vista Pro 70 Irons

Head number	7	8	9	Wedges
Tip trim	3"	3.5"	4"	4"
Butt Trim To Length				

All Other Wood Shafts

Recommended butt trim only. For those trying to fine tune a player, you may tip trim for the higher lofted fairway clubs:

5 = 1/2", # 7 = 1", # 9 = 1 1/2"