

# CLUBMATE GOLF AUSTRALIA

## Trimming Instructions

You will find the chart to be used in the corresponding line of your invoice!

### CHART C - iron shafts only

**First** trim from the **tip** as listed in the following charts, then trim the **butt** to final playing length.

Example: If you want to cut the shaft for a #5 iron and chart C2 is suggested on your invoice, the tip trim should be 2".

Iron >	=TWGT	#1	#2	#3	#4	#5	#6	#7	#8	#9	PW	SW	LW
C1	-	1"	1.5"	2"	2.5"	3"	3.5"	4"	4.5"	5"	5.5"	5.5"	5.5"
C2	D	0"	0.5"	1"	1.5"	2"	2.5"	3"	3.5"	4"	4"	4"	4"
C3	-	3"	3.5"	4"	4.5"	5"	5.5"	6"	6.5"	7"	7.5"	7.5"	7.5"
C4	-	-	-	0"	0.5"	1"	1.5"	2"	2.5"	3"	3.5"	3.5"	3.5"
C5	E	-	0"	0.25"	0.5"	0.75"	1"	1.25"	1.5"	1.75"	2"	2"	2"
C6	H	5"	5.5"	6"	6.5"	7"	-	-	-	-	-	-	-
C7	-	2"	2.5"	3"	3.5"	4"	4.5"	5"	5.5"	6"	6.5"	6.5"	6.5"
C8	F	-	0"	0.5"	1"	1.5"	2"	2.5"	3"	3.5"	4"	4"	4"

### CHART D - wood shafts only (with Standard Bore) \*

First trim from the **tip** as listed in the following charts, then trim the **butt** to final playing length.

Wood>	=TWGT	#1	#3	#5	#7	#9	#11
D1	-	1"	2"	3"	3"	3"	3"
D2	A alt./ C	0"	0.5"	1"	1.5"	1.5"	1.5"
D3	B alt.	0"	0.375"	0.75"	1.125"	1.5"	1.875"
D4	-	1.5"	2"	2.5"	2.5"	2.5"	2.5"
D6	-	1.5"	2.5"	3.5"	4.5"	4.5"	4.5"
D7	-	2"	2.5"	3"	3.5"	3.5"	3.5"
D8*	-	1.25"	1.75"	2.25"	2.25"	2.25"	2.25"
D9	A	0"	1"	2"	2.5"	2.5"	2.5"
D10*	-	3"	3.5"	4"	4"	4"	4"
D11	-	0"	0"	0"	0.5"	1"	-
D12	-	0"	1"	2"	2"	2"	2"
D13	-	0"	0"	1"	2"	2"	2"
D14	-	1"	1.25"	1.75"	1.75"	1.75"	1.75"
D15	-	3.5"	3.75"	4.25"	4.25"	4.25"	4.25"
D16	-	0"	0"	0.5"	1"	1.5"	1.5"

\* For **Through Bore** (shaft is inserted through the entire clubhead) trim 1,25" less from the tip,

\* For **Blind Bore** (shaft insertion depth of 1 ¼" to 2") trim 0,75" less from the tip.

### CHART E (no equivalent in TWGT)

- Step: For R/S combo flex shafts **first** trim from the **butt** as following: for soft R-Flex = 4", for firm R-Flex = 2.75", for soft S-Flex = 1.5" and for firm S-Flex = 0". A/L combo flex shafts **first** trim from the **butt** as following: for soft L-Flex = 4", for firm L-Flex = 2.75", for soft A-Flex = 1.5" and for firm A-Flex = 0"
- Step: Trim from the **tip** to final playing length.